allure[®] Transitional Shades

Specialty Shapes



Tools Needed

#6 Hex Head Provided	< <u></u>
Wall Anchors Not Provided	
Sheet Metal Not Provided	Antonia (II)
Fastners	

Installation Instructions Variations are the appeal of Allure...

Thank you for choosing Allure Transitional Shades. With proper installation and care, your new shades will provide many years of beauty and performance.

BEFORE INSTALLING

The exclusive processes used in weaving these materials create

distinctive variations and you may see various threads or slubs woven into the fabric creating light or dark colors intermittently dispersed throughout. These variations are intentional and add to the beauty and truly unique appearance of each shade.


Remove shade from the package. Keep all packaging until the shade operates to your satisfaction. Contents of your hardware package may vary depending on options chosen. Additional fasteners may be needed based on your specific mounting surface.

Outside Mount

(not recommended)

Drill and screw directly into board and into the mounting surface.

Inside Mount




- Space Button Catches evenly across your Specialty Shape and mark
- mounting surface
- Attach brackets to mounting surface using the screw provided

Step 1




Step 3



Space Button Catches evenly in window opening






Place Buttons with screws into the Button Catches. Line up your Specialty Shape and press against screws


Use the marks that the screws made as a guide to install the Button Screws by turning directly into the Specialty Shape

Step 4



Snap buttons into the button catches in the opening to install the Specialty Shape





The shading can be feather dusted or vacuumed at a low setting. Spots can be cleaned with a damp sponge and mild soap. To avoid discoloration, do not use chemical cleaners. Ultrasonic cleaning is not recommended. It will damage the shade.